

Corner Filler (BC-1) Installation Pictures

The BC-1 filler is designed to fill the corners at bay windows and angled walls that are at 45 degrees. The filler is non-structural and can be pieced together for walls over 8' tall. See the pictures below for typical installations (click on pictures to enlarge):

2x4 Walls: Use as is without fillers.



2x6 Walls: Requires a 1x4 filler on each side.

